



## **Cabinet Installation Recommendations**

- All cabinet runs have been pre-assembled and mocked up in shop to ensure fit, reveals, and function.
- BTW recommends that you remove and install toe kicks independently before cabinet placement (optional). Toe Kicks are deliberately built  $\frac{3}{4}$  inch shorter than your designed install height. We recommend using adjustable feet.
- Panels, soffits, toe skins, flat crown, and fillers have 1 inch of scribe to use for custom fit. Account for this in your installation wherever a panel meets a wall, floor, or ceiling.
- Drawer slides, hinges, and convenience hardware allow for adjustment post install.
- Please call us if you have questions about your installation:
  - Paul Gorman, Project Lead, 323.472.1502
  - Melissa Heron, Project Lead, 630.923.8340
  - Nathan Weiss, Shop Foreman, 707.529.3452